

ZTE


MF293N

Let's go


Getting started with your device.

1. Prepare

- A valid nano-SIM card.




- View the label on your device to get the default information. The following figure is for your reference only.




2. Insert the nano-SIM Card

Insert the nano-SIM card.




3. Connect the Power Adapter

Connect the power adapter to your device.




4. Start Your Device

Connect the power adapter to start your device and then the device will connect to the Internet automatically.




5. Access the Internet

- **Wi-Fi:** Get the default SSID and password on the label and connect to the Wi-Fi network with your mobile device, and then access the Internet.




- **Network cable(RJ45):** Connect with the computer via a LAN port and access the Internet.



6. Change Your Device Settings

You can change the device settings by logging in to the 4G CPE configuration web page.

1. View the label on your device to get the default *Device Manager Website IP address* and *Password*.




2. Launch the Internet browser and enter the *Device Manager Website IP address* in the address bar.
3. Input the password and then click **Login**.
4. After the 4G CPE configuration web page is opened, you can change the Wi-Fi SSID, password or other settings.

Cable Broadband Mode

Your device supports the cable broadband mode and you can use this service from your service provider to access the Internet.

1. Connect the LAN1/WAN port and the broadband service network port with a network cable.
2. Log in to the 4G CPE configuration web page.
3. Change the operation mode to **Cable Broadband Mode**.
4. Set the detailed parameters got from your service provider.
5. Use your clients to access the Internet.




Telephone

Your device supports the telephone function. Before using the telephone function, connect the telephone and insert the nano-SIM card.

To make a call:

1. Pick up the handset.
2. Dial the telephone number.
3. Wait for the call to be connected.






WPS

Your device supports the WPS function. You can use this function to connect a client to your device.

1. Press the **WPS** button on your device to activate the WPS function.
2. Enable the WPS function on your client.
3. Follow the system prompts on your client to establish the connection.

Indicator Lights and Interfaces



1. POWER



White on: Power is on and external power supply is working normally.
Off: Power is off or external power supply is working abnormally.

2. WIFI



White on: Wi-Fi works normally with no data transmission.
White blinking: WPS activating, normal for 2 minutes each time.
Off: Wi-Fi works abnormally or power saving mode.

3. SIG



Red: The device is turned on but not registered to the mobile network.
White blinking: The device is connected to the 4G LTE network and data is being transferred.
White solid: The device is registered to the 4G LTE network.
Green blinking: The device is connected to the 2G/3G network and data is being transferred.
Green solid: The device is registered to the 2G/3G network.
Off: Power saving mode.

4. External antenna
ports

Connect to the external antenna.

5. WPS

Press to activate the WPS function.

6. WAN/LAN port

Connect to computer or other network devices.
LAN1/WAN port: Connect this port to the WAN in the Cable Broadband Mode.

7. PHONE port

Connect to telephones.

8. POWER port

Connect to the power adapter.

9.	RESET	Press and hold for about 3 seconds to restore factory default configurations.
10.	nano-SIM card slot	Insert your nano-SIM card.
11.	USB port	Only used by manufacturer.
12.	LAN status indication LED	White: Connect this port to the WAN with no data transmission. White blinking: Connect this port to the WAN and data is being transferred.

Troubleshooting

Voice Related Problems

Symptoms	Possible Problems/ Solutions
There is no dial tone.	<ul style="list-style-type: none">● Please wait for 1~2 minutes after the device is turned on.● If the SIG indicator is blinking, you have no good RF reception. Change the location of the device.
There is a prompt / phone alert / announcement as soon as I lift the phone off the hook.	Make sure your nano-SIM card is inserted correctly and the PIN number has been entered. If the PIN number has been entered incorrectly then you will need to enter the PUK code when prompted.
The line is noisy/distorted when I lift the phone off the hook.	<ul style="list-style-type: none">● Remove any electrical appliance which is too close to the phone or your device.● The cable or phone set might be faulty.
I hear a rapid engaged tone as soon as I lift the phone off the hook.	<ul style="list-style-type: none">● Put the phone on the hook and try again.● Please contact your service provider.
After dialing the last digit I hear nothing/silence.	When you have finished dialing you can press the # key or wait 4~8 seconds to connect the call.

Internet Related Problems

Symptoms	Possible Problems / Solutions
I cannot access the Internet at all.	<ul style="list-style-type: none">● Please check your configuration settings.● Please wait 1~ 2 minutes for the device to initialize.● Check your network indicators.
The download or upload speed is very slow.	The speed is dependent on signal strength. Check your signal strength and network type.
I cannot visit the 4G CPE configuration web page.	<ul style="list-style-type: none">● Enter the correct IP address. You can view the label on your device to get the default IP address.● Only use one network adapter in your PC.● Do not use any proxy server.
I cannot establish the Wi-Fi connection between my device and the client.	<ul style="list-style-type: none">● Make sure the Wi-Fi function is active.● Refresh network list and select the correct SSID.● Check the IP address to make sure your client can obtain an IP address automatically in the Internet protocol (TCP/IP) properties.● Type the correct network key (Wi-Fi password) when you connect to the device.

Others

Symptoms	Possible Problems / Solutions
The 3G/4G signal indicator does not light.	This indicates poor reception. Try moving the device to another location near the window.
About the password	<ul style="list-style-type: none">● For the Wi-Fi connection password, please check the label on the device.● Please check the label on your device to get the default password of the 4G CPE configuration web page.● If you changed the password and forgot the new password, you need to restore the device to the factory default settings.

Getting More Help

You can get help by:

- Sending an email to **mobile@zte.com.cn**
- Visiting **www.ztedevices.com**

LEGAL INFORMATION

Copyright © 2020 ZTE CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

Notice

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

Disclaimer

Images and screenshots used in this guide may differ from the actual product. Content in this guide may differ from the actual product or software.

Trademarks

ZTE and the ZTE logos are trademarks of ZTE Corporation.

Other trademarks and trade names are those of their respective owners.

Version No.: R1.0

Warning and Notice

Safety Precautions

- Some electronic devices may be susceptible to electromagnetic interference. Locate the device away from TV set, radio and other electronic equipment to avoid electromagnetic interference.
- The device may interfere with medical devices like hearing aids and pacemakers. Consult a physician or the manufacturer of the medical device before using it.
- Please keep yourself at least 20 centimeters away from your device.
- Do not use your device in dangerous environments such as oil terminals or chemical factories where there are explosive gases or explosive products being processed.
- Please use original accessories or accessories that are authorized by ZTE. Unauthorized accessories may affect the device performance, damage the device or cause danger to you.
- Do not attempt to dismantle the device. There are no user-serviceable parts.
- Do not allow the device or accessories to come into contact with liquid or moisture at any time. Do not immerse the device in any liquid.
- Do not place objects on top of the device. This may lead to overheating of the device.
- The device must be placed in a well-ventilated environment for use.
- Do not expose the device to direct sunlight or store it in hot areas. High temperature can shorten the life of electronic devices.
- Do not allow children to play with the device or power adapter.
- The device is for indoor use only. Do not use the device outside.
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Cleaning and Maintaining

- Use an antistatic cloth to clean the device. Do not use chemical or abrasive cleanser as these could damage the plastic case. Turn off your device before you clean it.

- Use the device within the temperature range of -20°C ~ +55°C, and the storage temperature range is -40°C ~ +70°C. The humidity range is 5%~95%.
- Do not use your device during a thunderstorm. Remove the mains power pack from the wall socket.

Limited Warranty

This warranty does not apply to defects or errors in the product caused by:

- i. Reasonable abrasion.
- ii. End users' failure to follow ZTE's installation, operation or maintenance instructions or procedures.
- iii. End users' mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing or operation of the product.
- iv. Modifications or repairs not provided by ZTE or a ZTE-certified individual.
- v. Power failures, surges, fire, flood, accidents, and actions of third parties or other events outside ZTE's reasonable control.
- vi. Usage of third-party products or usage in conjunction with third-party products if such defects are due to the combined usage.
- vii. Any other cause beyond the range of normal usage intended for the product.

End users have no right to reject or return the product, or receive a refund for the product from ZTE under the above-mentioned situations.

This warranty is end users' sole remedy and ZTE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

Limitation of Liability

ZTE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, no matter whether or not ZTE had been advised, knew or should have known of the possibility of such damages, including, but not limited to lost profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime cost.

ZTE CORPORATION

NO. 55, Hi-tech Road South, Shenzhen, P.R.China

Postcode: 518057